QUICK SETUP

Model: HT-S9400THX



Speaker Configuration

5.1-channel: ① ② ③ ④ ⑤ ⑥

7.1-channel: ① ② ③ ④ ⑤ ⑥ + 7 8



• Please connect ①, ②, ③, ④, ⑤ and ⑥, when connecting 5.1-channel surround.

* Either the SURROUND BACK or FRONT HIGH speakers can be connected to 7 and 8. Change the settings in accordance with the connected speakers.

(C) Copyright 2011 ONKYO SOUND & VISION CORPORATION Japan. All rights reserved.

SN 29400664

Y1103-1

* 2 9 4 0 0 6 6 4 *

HDMI

Connecting a TV with Audio Return Channel



Please turn on HDMI Control (RIHD) from the setup menu.

Connecting a TV without Audio Return Channel



When there is no OPTICAL output in the TV, connect the analog output. The function of HDMI THRU can be used by turning on HDMI Control (RIHD) from the setup menu.

OTHERS



Make a connection with the MONITOR OUT V when you watch videos on the TV.

Connecting a Portable Player